


Intersecting Wall Detail

TYPICAL DETAIL FOR INTERSECTING WALLS
INCLUDING INTERIOR LINING



Benex Walls can be arranged in many positions
to suit your design.

Intersecting Benex Walls are simply erected & mechanically fixed during the installation with “Bugle Head” or Batten Screws. Concrete “Core-filling” at intersecting walls is normally advised to add strength to the join.